



OM-294494H

2026-04

Processes



MIG (GMAW) Welding



Flux Cored (FCAW) Welding



Description



Arc Welding Power Source

Auto Deltaweld™ 500/ 600

(208-230/460 Volt Model)



For product information,
Owner's Manual translations,
and more, visit

www.MillerWelds.com

OWNER'S MANUAL

From Miller to You

Thank you and congratulations on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety Precautions. They will help you protect yourself against potential hazards on the worksite. We've made installation and operation quick and easy. With Miller, you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is, and our extensive service network is there to help fix the problem. Warranty and maintenance information for your particular model are also provided.

Miller Electric manufactures a full line of welders and welding-related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual specification sheets. **To locate your nearest distributor or service agency call**

1-800-4-A-Miller, or visit us at www.MillerWelds.com on the web.



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.



Miller is the first welding equipment manufacturer in the U.S.A. to be registered to the ISO 9001 Quality System Standard.



TABLE OF CONTENTS

SECTION 1 – SAFETY PRECAUTIONS – READ BEFORE USING	1
1-1 Symbol Usage	1
1-2 Arc Welding Hazards	1
1-3 Additional Hazards For Installation, Operation, And Maintenance	3
1-4 California Proposition 65 Warnings	4
1-5 Principal Safety Standards	4
1-6 EMF Information	4
SECTION 2 – CONSIGNES DE SÉCURITÉ - LIRE AVANT UTILISATION	5
2-1 Symboles utilisés	5
2-2 Dangers relatifs au soudage à l'arc	5
2-3 Symboles de dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance	7
2-4 Proposition californienne 65 Avertissements	8
2-5 Principales normes de sécurité	9
2-6 Informations relatives aux CEM	9
SECTION 3 – SPECIFICATIONS	10
3-1 Features And Benefits	10
3-2 Serial Number And Rating Label Location	10
3-3 Unit Specifications	10
3-4 Dimensions And Weight	11
3-5 Static Output Characteristics	11
SECTION 4 – INSTALLATION	12
4-1 Selecting A Location	12
4-2 Selecting Input Voltage	13
4-3 Selecting Cable Sizes ¹	14
4-4 Weld Output Terminals	14
4-5 Connecting Weld Output Cables	15
4-6 Supplementary Protectors	15
4-7 Electrical Service Guide	16
4-8 Connecting Input Power	17
SECTION 5 – RECOMMENDED SET-UP PROCEDURES	19
5-1 Typical Connection For GMAW/GMAW-P/FCAW Process	19
5-2 Welding Circuit	20
5-3 Arranging Welding Cables To Reduce Welding Circuit Inductance	21
5-4 Using Multiple Welding Power Sources	22
5-5 Voltage Sensing Lead And Work Cable Connections For Multiple Welding Arcs	23
5-6 Voltage Sensing Lead And Work Cable Connections For Multiple Welding Arcs (continued)	24
5-7 Earth Grounding	25
5-8 30 Points Of Mechanics In MIG Welding	26
5-9 Arc Blow	27
5-10 Basic Welding Troubleshooting	27
SECTION 6 – GENERAL OPERATION	30
6-1 Front Panel	30
6-2 Rear Panel	31
6-3 Updating Software	31
6-4 Obtaining Service.TXT file	31
6-5 Duty Cycle And Overheating (500 Models And 600 Models When Connected To 208/230 VAC)	32
6-6 Duty Cycle And Overheating (600 Models When Connected to 460 VAC)	33
SECTION 7 – INTERFACE CONFIGURATION	34
7-1 Connecting a PC	34
7-2 Auto-Deltaweld Configuration Main Page	34
7-3 Machine Configuration Page	38
SECTION 8 – MAINTENANCE AND TROUBLESHOOTING	39
8-1 Routine Maintenance	39
8-2 Blowing Out Inside Of Unit	39
8-3 Fault Codes	39
8-4 Fault Code Diagnostics	40
8-5 Troubleshooting	40
SECTION 9 – ELECTRICAL DIAGRAMS	42
SECTION 10 – DEFINITIONS	44
10-1 Additional Safety Symbol Definitions	44
10-2 Miscellaneous Symbols And Definitions	46
SECTION 11 – REGULATORY AND COMPLIANCE INFORMATION	47

TABLE OF CONTENTS

11-1	Software Licensing Agreement	47
11-2	Information About Default Weld Parameters And Settings	47
11-3	Environmental Specifications	47

SECTION 1 – SAFETY PRECAUTIONS – READ BEFORE USING

 Protect yourself and others from injury—read, follow, and save these important safety precautions and operating instructions.

1-1. Symbol Usage

 **DANGER!** – Indicates a hazardous situation which, if not avoided, will result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

 Indicates a hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

NOTICE – Indicates statements not related to personal injury.

 Indicates special instructions.



This group of symbols means Warning! Watch Out! **ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS** hazards. Consult symbols and related instructions below for necessary actions to avoid these hazards.

1-2. Arc Welding Hazards

 The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Principal Safety Standards. Read and follow all Safety Standards.

 Only qualified persons should install, operate, maintain, and repair this equipment. A qualified person is defined as one who, by possession of a recognized degree, certificate, or professional standing, or who by extensive knowledge, training and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter, the work, or the project and has received safety training to recognize and avoid the hazards involved.

 During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on.

The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC weld output in damp, wet, or confined spaces, or if there is a danger of falling.
- Do not store or use equipment in standing water.
- Use AC output **ONLY** if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welding power source,

2) a DC manual (stick) welding power source, or 3) an AC welding power source with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welding power source is recommended. And, do not work alone!


- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install, ground, and operate this equipment according to its Owner's Manual and national, state, and local codes.
- Always verify the supply ground—check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first—double-check connections.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cord and ground conductor for damage or bare wiring—replace immediately if damaged—bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or repaired cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Do not touch electrode holders connected to two welding machines at the same time because double open-circuit voltage can be present.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal. Disconnect cable for process not in use.
- Use GFCI protection when operating auxiliary equipment in damp or wet locations.



HOT PARTS can burn.

- Do not touch hot parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to

prevent burns.



FLYING METAL OR DIRT can injure eyes.

Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.

- Wear approved safety glasses with side shields even under your welding helmet.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- Ventilate the work area and/or use local forced ventilation at the arc to remove welding fumes and gases. The recommended way to determine adequate ventilation is to sample for the composition and quantity of fumes and gases to which personnel are exposed.
- If ventilation is poor, wear an approved air-supplied respirator.
- Read and understand the Safety Data Sheets (SDSs) and the manufacturer's instructions for adhesives, coatings, cleaners, consumables, coolants, degreasers, fluxes, and metals.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watchperson nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and the operator is wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



BUILDUP OF GAS can injure or kill.


- Shut off compressed gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.


- Wear an approved welding helmet fitted with a proper shade of filter lenses to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash, glare, and sparks; warn others not to watch the arc.
- Wear body protection made from leather or flame-resistant clothing (FRC). Body protection includes oil-free clothing such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.



WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Do not weld where flying sparks can strike flammable material.
- Protect yourself and others from flying sparks and hot metal.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not cut or weld on tire rims or wheels. Tires can explode if heated. Repaired rims and wheels can fail. See OSHA 29 CFR 1910.177 listed in Safety Standards.
- Do not weld on containers that have held combustibles, or on closed containers such as tanks, drums, or pipes unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Do not weld where the atmosphere can contain flammable dust, gas, or liquid vapors (such as gasoline).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths.
- Do not use welding power source to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear body protection made from leather or flame-resistant clothing (FRC). Body protection includes oil-free clothing such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Use only correct fuses or circuit breakers. Do not oversize or bypass them.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.
- Read and understand the Safety Data Sheets (SDSs) and the manufacturer's instructions for adhesives, coatings, cleaners, consumables, coolants, degreasers, fluxes, and metals.



NOISE can damage hearing.


Noise from some processes or equipment can damage hearing.

- Check for noise level limits exceeding those specified by OSHA.
- Wear appropriate ear protection if noise level is high.
- Warn others nearby about noise hazard.



ELECTRIC AND MAGNETIC FIELDS (EMF) can affect Implanted Medical Devices.

- Wearers of pacemakers and other implanted medical devices should keep away.
- Implanted medical device wearers should consult their doctor and the device manufacturer before going near arc welding, spot welding, arc gouging, plasma arc cutting, or induction heating operations.



CYLINDERS can explode if damaged.

Compressed gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.

- Never weld on a pressurized cylinder—explosion will result.
- Use only correct compressed gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve. Do not stand in front of or behind the regulator when opening the valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the proper equipment, correct procedures, and sufficient number of persons to lift, move, and transport cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.

1-3. Additional Hazards For Installation, Operation, And Maintenance




FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring—be sure power supply system is properly sized, rated, and protected to handle this unit.




FALLING EQUIPMENT can injure.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use correct procedures and equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.
- Keep equipment (cables and cords) away from moving vehicles when working from an aerial location.
- Follow the guidelines in the Applications Manual for the Revised NIOSH Lifting Equation (Publication No. 94-110) when manually lifting heavy parts or equipment.



OVERUSE can cause OVERHEATING.

- Allow cooling period; follow rated duty cycle.
- Reduce output or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.



FLYING SPARKS can injure.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location while wearing proper face, hand, and body protection.
- Sparks can cause fires—keep flammables away.




MOVING PARTS can injure.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.



WELDING WIRE can injure.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.




BATTERY EXPLOSION can injure.

- Do not use welding power source to charge batteries or jump start vehicles unless it has a battery charging feature designed for this purpose.



MOVING PARTS can injure.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Have only qualified persons remove doors, panels, guards for maintenance and troubleshooting as necessary.
- Reinstall doors, panels, covers, or guards when maintenance is finished and before reconnecting input power.



READ INSTRUCTIONS.

- Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.
- Use only genuine replacement parts from the manufacturer.
- Perform installation, maintenance, and service according to the Owner's Manuals, industry standards, and national, state, and local codes.



HF RADIATION can cause interference.

- High-frequency (HF) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as microprocessors, computers, and computer-driven equipment such

as robots.

- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.

- Be sure this welding equipment is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding equipment, using shielded cables, using line filters, or shielding the work area.

1-4. California Proposition 65 Warnings



WARNING – This product can expose you to chemicals including lead, which are known to the state of California to cause cancer and birth defects or other reproductive harm.

For more information, go to www.P65Warnings.ca.gov.

1-5. Principal Safety Standards

Safety in Welding, Cutting, and Allied Processes, American Welding Society standard ANSI Standard Z49.1. Website: www.aws.org.

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute. Website: safetyequipment.org.

Safe Practices for the Preparation of Containers and Piping for Welding and Cutting, American Welding Society Standard AWS F4.1. Website: www.aws.org.

National Electrical Code, NFPA Standard 70 from National Fire Protection Association. Website: www.nfpa.org.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1 from Compressed Gas Association. Website: www.cganet.com.

Safety in Welding, Cutting, and Allied Processes, CSA Standard W117.2 from Canadian Standards Association. Website: www.csagroup.org.

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B from National Fire Protection Association. Website: www.nfpa.org.

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910.177 Subpart N, Part 1910 Subpart Q, and Part 1926, Subpart J. Website: www.osha.gov.

OSHA *Important Note Regarding the ACGIH TLV, Policy Statement on the Uses of TLVs and BEIs*. Website: www.osha.gov.

Applications Manual for the Revised NIOSH Lifting Equation from the National Institute for Occupational Safety and Health (NIOSH). Website: www.cdc.gov/NIOSH.

SOM 2026–02

1-6. EMF Information

Electric current flowing through any conductor causes localized electric and magnetic fields (EMF). The current from arc welding (and allied processes including spot welding, arc gouging, plasma arc cutting, and induction heating operations) creates EMF around the welding circuit. EMF can interfere with some medical implants, e.g. pacemakers. Protective measures for persons wearing medical implants have to be taken. For example, restrict access for passersby or conduct individual risk assessment for operators. All operators should use the following procedures in order to minimize exposure to EMF fields:

1. Keep cables close together by twisting or taping them, or using a cable cover.
2. Do not place your body between cables. Arrange cables to one side and away from the operator.

3. Do not coil or drape cables around your body.
4. Keep head and trunk as far away from the equipment in the output circuit as possible.
5. Connect work clamp to workpiece as close to the arc as possible.
6. Do not work next to, sit or lean on, or carry the power source or other equipment while operating.

About Implanted Medical Devices:

Implanted Medical Device wearers should consult their doctor and the device manufacturer before performing or going near arc welding, spot welding, arc gouging, plasma arc cutting, or induction heating operations. If cleared by your doctor, follow the procedures above.

SECTION 2 – CONSIGNES DE SÉCURITÉ - LIRE AVANT UTILISATION

 Pour écarter les risques de blessure pour vous-même et pour autrui — lire, appliquer et ranger en lieu sûr ces consignes relatives aux précautions de sécurité et au mode opératoire.

2-1. Symboles utilisés

 **DANGER!** – Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.

 Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.

AVIS – Indique des déclarations pas en relation avec des blessures personnelles.

 Indique des instructions spécifiques.



Ce groupe de symboles veut dire Avertissement! Attention! DANGER DE CHOC ELECTRIQUE, PIECES EN MOUVEMENT, et PIECES CHAUDES. Reportez-vous aux symboles et aux directives ci-dessous afin de connaître les mesures à prendre pour éviter tout danger.

2-2. Dangers relatifs au soudage à l'arc

 Les symboles représentés ci-dessous sont utilisés dans ce manuel pour attirer l'attention et identifier les dangers possibles. En présence de ce symbole, prendre garde et suivre les instructions afférentes pour éviter tout risque. Les consignes de sécurité présentées ci-après ne font que résumer l'information contenue dans les Normes de sécurité principales. Lire et suivre toutes les Normes de sécurité.

 L'installation, l'utilisation, l'entretien et les réparations ne doivent être confiés qu'à des personnes qualifiées. Une personne qualifiée est définie comme celle qui, par la possession d'un diplôme reconnu, d'un certificat ou d'un statut professionnel, ou qui, par une connaissance, une formation et une expérience approfondies, a démontré avec succès sa capacité à résoudre les problèmes liés à la tâche, le travail ou le projet et a reçu une formation en sécurité afin de reconnaître et d'éviter les risques inhérents.

 Au cours de l'utilisation, tenir toute personne à l'écart et plus particulièrement les enfants.



UNE DÉCHARGE ÉLECTRIQUE peut entraîner la mort.

Le contact d'organes électriques sous tension peut provoquer des accidents mortels ou des brûlures graves. Le circuit de l'électrode et de la pièce est sous tension lorsque le courant est délivré à la sortie. Le circuit d'alimentation et les circuits internes de la machine sont également sous tension lorsque l'alimentation est sur Marche. Dans le mode de soudage avec du fil, le fil, le dérouleur, le bloc de commande du rouleau et toutes les parties métalliques en contact avec le fil sont sous tension électrique. Un équipement installé ou mis à la terre de manière incorrecte ou impropre constitue un danger.

- Ne pas toucher aux pièces électriques sous tension.
- Porter des gants isolants et des vêtements de protection secs et sans trous.
- S'isoler de la pièce à couper et du sol en utilisant des housses ou des tapis assez grands afin d'éviter tout contact physique avec la pièce à couper ou le sol.
- Ne pas utiliser de sortie de soudage CA dans des zones humides ou confinées ou s'il y a un risque de chute.
- Ne stockez pas et n'utilisez pas l'équipement dans de l'eau stagnante.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.


- D'autres consignes de sécurité sont nécessaires dans les conditions suivantes : risques électriques dans un environnement humide ou si l'on porte des vêtements mouillés ; sur des structures métalliques telles que sols, grilles ou échafaudages ; en position coincée comme assise, à genoux ou couchée ; ou s'il y a un risque élevé de contact inévitable ou accidentel avec la pièce à souder ou le sol. Dans ces conditions, utiliser les équipements suivants, dans l'ordre indiqué : 1) un source d'alimentation de soudage DC à tension constante (à fil), 2) un source d'alimentation de soudage DC manuel (électrode) ou 3) un source d'alimentation de soudage AC à tension à vide réduite. Dans la plupart des situations, l'utilisation d'un source d'alimentation de soudage DC à fil à tension constante est recommandée. En outre, ne pas travailler seul!
- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Brancher correctement la mise à la terre et utiliser cet appareil conformément à son manuel d'utilisateur et aux codes nationaux, provinciaux et municipaux.
- Toujours vérifier la mise à la terre — vérifier et assurez-vous que le conducteur de mise à la terre du cordon d'alimentation est bien raccordé à la borne de mise à la terre dans le boîtier de déconnexion ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
- En effectuant les raccordements d'entrée, fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Les câbles doivent être exempts d'humidité, d'huile et de graisse; protégez-les contre les étincelles et les pièces métalliques chaudes.
- Vérifier fréquemment le cordon d'alimentation et le conducteur de mise à la terre afin de s'assurer qu'il n'est pas altéré ou dénudé -, le remplacer immédiatement s'il l'est -. Un fil dénudé peut entraîner la mort.
- L'équipement doit être hors tension lorsqu'il n'est pas utilisé.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épissés.
- Ne pas enrouler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct.
- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretenir l'appareil conformément à ce manuel.

- Ne pas toucher des porte électrodes connectés à deux machines en même temps à cause de la présence d'une tension à vide doublée.
- Porter un harnais de sécurité si l'on doit travailler au-dessus du sol.
- S'assurer que tous les panneaux et couvercles sont correctement en place.
- Fixer le câble de retour de façon à obtenir un bon contact métal à métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.
- Ne pas raccorder plus d'une électrode ou plus d'un câble de masse à une même borne de sortie de soudage. Débrancher le câble pour le procédé non utilisé.
- Utiliser une protection différentielle lors de l'utilisation d'un équipement auxiliaire dans des endroits humides ou mouillés.



LES PIÈCES CHAUDES peuvent provoquer des brûlures.

- Ne pas toucher des parties chaudes à mains nues.
- Prévoir une période de refroidissement avant de travailler à l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



DES PIÈCES DE METAL ou DES SALETES peuvent provoquer des blessures dans les yeux.

Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.

- Porter des protections approuvées pour les oreilles si le niveau sonore est trop élevé.



LES FUMÉES ET LES GAZ peuvent être dangereux.

Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereux pour votre santé.


- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- Ventiler la zone et/ou utiliser une ventilation forcée au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage. Pour déterminer la bonne ventilation, il est recommandé de procéder à un prélèvement pour la composition et la quantité de fumées et de gaz auxquelles est exposé le personnel.
- Si la ventilation est médiocre, porter un respirateur anti-vapeurs approuvé.
- Lire et comprendre les fiches de données de sécurité et les instructions du fabricant concernant les adhésifs, les revêtements, les nettoyants, les consommables, les produits de refroidissement, les dégraissants, les flux et les métaux.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit

bien ventilé, et de l'opérateur est portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz comprimé en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.



LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intenses (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.

- Portez un casque de soudage approuvé muni de verres filtrants appropriés pour protéger visage et yeux contre les rayons et les étincelles d'arc pendant le soudage ou la surveillance (voir ANSI Z49.1 et Z87.1 énuméré dans les Normes de Sécurité).
- Porter des lunettes de sécurité avec écrans latéraux même sous votre casque.
- Avoir recours à des écrans protecteurs ou à des rideaux pour protéger les autres contre les rayonnements les éblouissements et les étincelles ; prévenir toute personne sur les lieux de ne pas regarder l'arc.
- Porter une protection corporelle en cuir ou des vêtements ignifuges (FRC). La protection du corps comporte des vêtements sans huile, comme des gants de cuir, une chemise solide, des pantalons sans revers, des chaussures hautes et une casquette.




LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tels que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologuées.
- Ne pas souder dans un endroit où des étincelles peuvent tomber sur des substances inflammables.
- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas couper ou souder des jantes ou des roues. Les pneus peuvent exploser s'ils sont chauffés. Les jantes et les roues réparées peuvent défailir. Voir OSHA 29 CFR 1910.177 énuméré dans les normes de sécurité.

- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 (voir les Normes de Sécurité).
- Ne pas souder là où l'air ambiant pourrait contenir des poussières, gaz ou émanations inflammables (vapeur d'essence, par exemple).
- Brancher le câble de masse sur la pièce la plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels.
- Ne pas utiliser le poste de soudage pour dégelier des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter une protection corporelle en cuir ou des vêtements ignifuges (FRC). La protection du corps comporte des vêtements sans huile, comme des gants de cuir, une chemise solide, des pantalons sans revers, des chaussures hautes et une casquette.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.
- Une fois le travail achevé, assurez-vous qu'il ne reste aucune trace d'étincelles incandescentes ni de flammes.
- Utiliser exclusivement des fusibles ou coupe-circuits appropriés. Ne pas augmenter leur puissance; ne pas les ponter.
- Suivre les recommandations dans OSHA 1910.252 (a) (2) (iv) et NFPA 51B pour les travaux à chaud et assurez-vous qu'un observateur d'incendie et un extincteur à proximité.
- Lire et comprendre les fiches de données de sécurité et les instructions du fabricant concernant les adhésifs, les revêtements, les nettoyeurs, les consommables, les produits de refroidissement, les dégraisseurs, les flux et les métaux.



Le BRUIT peut endommager l'ouïe.

Le bruit des processus et des équipements peut affecter l'ouïe.


- Vérifier si les niveaux de bruit excèdent les limites spécifiées par l'OSHA.
- Porter des protections appropriée pour les oreilles si le niveau sonore est trop élevé.
- Prévenez toute personne sur les lieux du danger relié au bruit.



Les CHAMPS ÉLECTROMAGNÉTIQUES (CEM) peuvent affecter les implants médicaux.

- Les porteurs de stimulateurs cardiaques et autres implants médicaux doivent rester à distance.

- Les porteurs d'implants médicaux doivent consulter leur médecin et le fabricant du dispositif avant de s'approcher de la zone où se déroule le soudage à l'arc, du soudage par points, gouge à l'arc, de la découpe plasma ou une opération de chauffage par induction.



Si des BOUTEILLES sont endommagées, elles pourront exploser.

Des bouteilles de gaz comprimé protecteur contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.

- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, des dommages physiques, du laitier, des flammes ouvertes, des étincelles et des arcs.
- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée - risque d'explosion.
- Utiliser seulement des bouteilles de gaz comprimé, régulateurs, tuyaux et raccords convenables pour cette application spécifique; les maintenir ainsi que les éléments associés en bon état.
- Tourner le dos à la sortie de vanne lors de l'ouverture de la vanne de la bouteille. Ne pas se tenir devant ou derrière le régulateur lors de l'ouverture de la vanne.
- Maintenir le chapeau de protection sur la soupape, sauf en cas d'utilisation ou de branchement de la bouteille.
- Utilisez les équipements corrects, les bonnes procédures et suffisamment de personnes pour soulever, déplacer et transporter les bouteilles.
- Lire et suivre les instructions sur les bouteilles de gaz comprimé, l'équipement connexe et le dépliant P-1 de la CGA (Compressed Gas Association) mentionné dans les principales normes de sécurité.

2-3. Symboles de dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance




Risque D'INCENDIE OU D'EXPLOSION.

- Ne pas installer ou placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Ne pas installer l'appareil à proximité de produits inflammables.
- Ne pas surcharger l'installation électrique – s'assurer que l'alimentation est correctement dimensionnée et protégée avant de mettre l'appareil en service.




LA CHUTE DE L'ÉQUIPEMENT peut provoquer des blessures.

- Utiliser l'anneau de levage uniquement pour soulever l'appareil, NON PAS les organes de roulement, les bouteilles de gaz ou tout autre accessoire.
- Utilisez les procédures correctes et des équipements d'une capacité appropriée pour soulever et supporter l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.
- Tenir l'équipement (câbles et cordons) à distance des véhicules mobiles lors de toute opération en hauteur.
- Suivre les consignes du Manuel des applications pour l'équation de levage NIOSH révisée (Publication N° 94–110) lors du levage manuel de pièces ou équipements lourds.



L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Laisser l'équipement refroidir ; respecter le facteur de marche nominal.
- Réduire le courant de sortie ou le cycle opératoire avant de recommencer le soudage.
- Ne pas obstruer les passages d'air du poste.



LES ÉTINCELLES PROJÉTÉES peuvent provoquer des blessures.

- Porter un écran facial pour protéger le visage et les yeux.
- Former l'électrode au tungstène uniquement à la meuleuse dotée de protecteurs cette manoeuvre est à exécuter dans un endroit sûr lorsque l'on porte l'équipement homologué de protection du visage, des mains et du corps.
- Les étincelles risquent de causer un incendie - éloigner toute substance inflammable.



Les PIÈCES MOBILES peuvent causer des blessures.

- Ne pas s'approcher des organes mobiles.
- Ne pas s'approcher des points de coincement tels que des rouleaux de commande.



LES FILS DE SOUDAGE peuvent provoquer des blessures.

- Ne pas appuyer sur la gachette avant d'en avoir reçu l'instruction.
- Ne pas diriger le pistolet vers soi, d'autres personnes ou toute pièce mécanique en engageant le fil de soudage.




L'EXPLOSION DE LA BATTERIE peut provoquer des blessures.

- Ne pas utiliser source d'alimentation de soudage pour charger des batteries ou faire démarrer des véhicules à l'aide de câbles de démarrage, sauf si l'appareil dispose d'une fonctionnalité de charge de batterie destinée à cet usage.



Les PIÈCES MOBILES peuvent causer des blessures.

- Rester à l'écart des organes mobiles comme le ventilateur.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.
- Lorsque cela est nécessaire pour des travaux d'entretien et de dépannage, faire retirer les portes, panneaux, recouvrements ou dispositifs de protection uniquement par du personnel qualifié.
- Remettre les portes, panneaux, recouvrements ou dispositifs de protection quand l'entretien est terminé et avant de rebrancher l'alimentation électrique.




LIRE LES INSTRUCTIONS.

- Lire et appliquer les instructions sur les étiquettes et le Mode d'emploi avant l'installation, l'utilisation ou l'entretien de l'appareil. Lire les informations de sécurité au début du manuel et dans chaque section.
- N'utiliser que des pièces de remplacement provenant du fabricant.
- Effectuer l'installation, l'entretien et toute intervention selon les manuels d'utilisateurs, les normes nationales, provinciales et de l'industrie, ainsi que les codes municipaux.



LE RAYONNEMENT HAUTE FRÉQUENCE (HF) risque de provoquer des interférences.

- Le rayonnement haute fréquence (HF) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.
- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.



LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique peut gêner le fonctionnement d'appareils électroniques sensibles tels que les microprocesseurs, les ordinateurs et les équipements informatisés comme les robots.
- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce l'équipement soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.

2-4. Proposition californienne 65 Avertissements



AVERTISSEMENT – Ce produit peut vous exposer à des produits chimiques tels que le plomb, reconnus par l'État de Californie comme cancérigènes et sources de malformations ou d'autres troubles de la reproduction.

Pour plus d'informations, consulter www.P65Warnings.ca.gov.

2-5. Principales normes de sécurité

Safety in Welding, Cutting, and Allied Processes, American Welding Society standard ANSI Standard Z49.1. Website: www.aws.org.

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute. Website: safetysupply.com.

Safe Practices for the Preparation of Containers and Piping for Welding and Cutting, American Welding Society Standard AWS F4.1. Website: www.aws.org.

National Electrical Code, NFPA Standard 70 from National Fire Protection Association. Website: www.nfpa.org.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1 from Compressed Gas Association. Website: www.cganet.com.

Safety in Welding, Cutting, and Allied Processes, CSA Standard W117.2 from Canadian Standards Association. Website: www.csa-group.org.

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B from National Fire Protection Association. Website: www.nfpa.org.

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910.177 Subpart N, Part 1910 Subpart Q, and Part 1926, Subpart J. Website: www.osha.gov.

OSHA *Important Note Regarding the ACGIH TLV, Policy Statement on the Uses of TLVs and BEIs*. Website: www.osha.gov.

Applications Manual for the Revised NIOSH Lifting Equation from the National Institute for Occupational Safety and Health (NIOSH). Website: www.cdc.gov/NIOSH.

SOM_fre 2026-02

2-6. Informations relatives aux CEM

Le courant électrique qui traverse tout conducteur génère des champs électromagnétiques (CEM) à certains endroits. Le courant issu d'un soudage à l'arc (et de procédés connexes, y compris le soudage par points, gouge à l'arc, le découpage plasma et les opérations de chauffage par induction) crée un CEM autour du circuit de soudage. CEM produits peuvent causer interférence à certains implants médicaux, p. ex. les stimulateurs cardiaques. Des mesures de protection pour les porteurs d'implants médicaux doivent être prises. Par exemple, des restrictions d'accès pour les passants ou une évaluation individuelle des risques pour les opérateurs. Tous les opérateurs doivent appliquer les procédures suivantes pour minimiser l'exposition aux CEM provenant du circuit de soudage:

1. Rassembler les câbles en les torsadant ou en les attachant avec du ruban adhésif ou avec une housse.
2. Ne pas se tenir au milieu des câbles. Disposer les câbles d'un côté et à distance de l'opérateur.

3. Ne pas courber et ne pas entourer les câbles autour de votre corps.
4. Maintenir la tête et le torse aussi loin que possible du matériel du circuit de sortie.
5. Connecter la pince sur la pièce aussi près que possible à l'arc.
6. Ne travaillez pas à côté, ne vous asseyez pas ou ne vous appuyez pas sur, et ne transportez pas le générateur ou d'autres équipements pendant l'opération.

En ce qui concerne les implants médicaux :

Les porteurs d'implants doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de soudage par points, de gouge à l'arc, du découpage plasma ou de chauffage par induction. Si votre médecin l'a autorisé, suivez les procédures ci-dessus.

SECTION 3 – SPECIFICATIONS

3-1. Features And Benefits

LVC[™] Line Voltage Compensation is circuitry that keeps the power source output constant regardless of input power fluctuation.

Wind Tunnel Technology[™] circulates air over components that require cooling, not over electronic circuitry, which reduces contaminants and improves reliability in harsh welding environments.

Fan-On-Demand[™] cooling system operates only when needed, reducing noise, energy use and the amount of contaminants pulled through the machine.

Thermal Overload Protection automatically shuts down the unit, only when necessary to prevent damage to internal components if the duty cycle is exceeded or air flow and cooling are restricted (see Section 6-5).

Auto Remote Sense enables the unit to automatically sense the connection of a remote control).

3-2. Serial Number And Rating Label Location

The serial number and rating information for this product is located on the rear panel. Use rating label to determine input power requirements and/or rated output. For future reference, write serial number in space provided on back cover of this manual.

3-3. Unit Specifications

Do not use information in unit specifications table to determine electrical service requirements. See Sections 4-7 and 4-8 for information on connecting input power.

This equipment will deliver rated output at an ambient air temperature up to 104°F (40°C).

A. Input Voltage And Current At Rated Output (500 Model And 600 Model When Connected To 208/230VAC)

Process	Output Ratings			Amperes Input At Rated Output (60 Hz)			Input Power (60 Hz Three Phase)	
	Current (Amperes)	Voltage (DC)	Duty Cycle (%)	208 VAC	230 VAC	460 VAC (500 Models Only)	KW	KVA
GMAW (MIG)	500	39	100	64.2	58.1	30.4	21.7	24.2
	575	42.75	60	80.2	73.5	38.0	27.2	30.3
	650	44	25	94.2	84.9	43.9	31.6	35.0
Idle (Fan Off)	N/A			0.74	0.89	0.52	0.084	0.41
Idle (Fan On)				0.80	0.97	0.55	0.126	0.44

B. Output Range (500 Model And 600 Model When Connected To 208/230VAC)

Process	Output Range	Rated No-Load Voltage (U ₀)	
		208 VAC	230/460 VAC
GMAW	10V-44V	70V	79V


C. Input Voltage And Current At Rated Output (600 Model When Connected to 460 VAC)

Process	Output Ratings			460 VAC	Input Power (60 Hz Three Phase)	
	Current (Amperes)	Voltage (DC)	Duty Cycle (%)		KW	KVA
GMAW (MIG)	600	44	100	40.55	29.06	32.34
	700	44	60	47.74	34.24	28.13
	750	44	40	51.10	36.71	40.77
Idle (Fan Off)	N/A			0.52	0.08	0.41
Idle (Fan On)				0.55	0.13	0.44

D. Output Range (600 Model When Connected to 460 VAC)

Process	Output Range	Rated No-Load Voltage (U ₀)	
		460 VAC	
GMAW	10V-44V	79V	

3-4. Dimensions And Weight




3-5. Static Output Characteristics


The static (output) characteristics of the welding power source can be described as *flat* during the GMAW, FCAW and SAW processes and *drooping* during the SMAW, CAC-A and GTAW processes. Static characteristics are also affected by control settings (including software), electrode, shielding gas, weldment material, and other factors. Contact the factory for specific information on the static characteristics of the welding power source.

SECTION 4 – INSTALLATION


4-1. Selecting A Location



Movement



Location And Airflow



Do not move or operate unit where it could tip.

Special installation may be required where gasoline or volatile liquids are present - see NEC Article 511 or CEC Section 20.

1 Lifting Forks


Use lifting forks to move unit.

Extend forks beyond opposite side of unit.

2 Line Disconnect Device

Locate unit near correct input power supply.

4-2. Selecting Input Voltage



- Turn off welding power source, and disconnect input power.
- Significant DC voltage can remain on capacitors after unit is OFF. Wait 5 minutes after input power has been disconnected to allow capacitors to discharge.
- Only a qualified person should re-link input power.

Check input voltage available at site.



Check voltage selected in unit. Changing selection is only necessary if selected value does not match input voltage.

- 1 Interconnect Board PC2
- 2 Relink Board PC8
- 3 Mounting Screws
- 4 208 Or 230 Volts
- 5 460 Volts

To change voltage selection, remove the six mounting screws attaching the relink board PC8.

Position relink board on interconnect board to match the available input voltage.

Secure relink board using the six mounting screws.



4-3. Selecting Cable Sizes¹

NOTICE – The Total Cable Length in Weld Circuit (see table below) is the combined length of both weld cables. For example, if the power source is 100 ft (30 m) from the workpiece, the total cable length in the weld circuit is 200 ft (2 cables x 100 ft). Use the 200 ft (60 m) column to determine cable size.

Select weld cables that meet all applicable local and national regulations.

	Weld Cable Size ^{2, 3} and Total Cable (Copper) Length in Weld Circuit Not Exceeding ⁴							
	100 ft (30 m) or Less		150 ft (45 m)	200 ft (60 m)	250 ft (70 m)	300 ft (90 m)	350 ft (105 m)	400 ft (120 m)
Welding Amperes	10 - 60% Duty Cycle AWG (mm ²)	60 - 100% Duty Cycle AWG (mm ²)	10 - 100% Duty Cycle AWG (mm ²)					
100	4 (20)	4 (20)	4 (20)	3 (30)	2 (35)	1 (50)	1/0 (60)	1/0 (60)
150	3 (30)	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	3/0 (95)
200	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	4/0 (120)
250	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x2/0 (2x70)
300	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x3/0 (2x95)
350	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x3/0 (2x95)	2x4/0 (2x120)
400	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	2x4/0 (2x120)
500	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)	3x3/0 (3x95)
600	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)	3x4/0 (3x120)	3x4/0 (3x120)
700	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)	3x4/0 (3x120)	3x4/0 (3x120)	4x4/0 (4x120)
800	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x4/0 (3x120)	3x4/0 (3x120)	4x4/0 (4x120)	4x4/0 (4x120)
900	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)				


¹ This chart is a general guideline and may not suit all applications. If cable overheats, use next size larger cable.

² Weld cable size (AWG) is based on either a drop of 4 volts or less or at least 300 circular mils per ampere.
() = mm² for metric use.

³ Recommended minimum weld cable size for GMAW-P applications is 4/0 (120).

⁴ For distances longer than those shown in this guide, see AWS Fact Sheet No. 39, Welding Cables, available from the American Welding Society at <http://www.aws.org>.

4-4. Weld Output Terminals



Ref. 295617-D


Turn off power before connecting to weld output terminals.

Do not use worn, damaged, undersized, or repaired cables.

- 1 Positive (+) Weld Output Terminal
- 2 Negative (-) Weld Output Terminal

See Section 4-5 for information on connecting to weld output terminals, and Section 5 for standard connection diagrams.

4-5. Connecting Weld Output Cables



Wrench 3/4 in. (19 mm)

Turn off power before connecting to weld output terminals.

Failure to properly connect weld cables may cause excessive heat and start a fire, or damage your machine.

Use correct size weld cables.

1 Weld Output Terminal

2 Supplied Weld Output Terminal Nut

3 Supplied Weld Output Terminal Bolt


4 Copper Bar

5 Weld Cable Terminal

Remove supplied Bolt and nut from weld output terminal. Secure weld cable terminals to weld output terminal with nut and bolt as

shown, so that weld cable terminal is tight against copper bar. **Do not place anything between weld cable terminal and copper bar. Make sure that the surfaces of the weld cable terminal and copper bar are clean.**

4-6. Supplementary Protectors



1 115 V 15 Amp AC Receptacle

2 Supplementary Protector CB1

3 Supplementary Protector CB2

CB1 protects duplex receptacle.

CB2 protects 50 volts DC portion of ArcConnect receptacle.

Press button to reset supplementary protector.

4-7. Electrical Service Guide

⚠ Failure to follow these electrical service guide recommendations could create an electric shock or fire hazard. These recommendations are for an individual branch circuit sized for the rated output and duty cycle of one welding power source. In individual branch circuit installations, the National Electrical Code (NEC) allows the receptacle or conductor rating to be less than the rating of the circuit protection device. All components of the circuit must be physically compatible. See NEC articles 210.21, 630.11, and 630.12.

NOTICE – Incorrect input power can damage this welding power source. Actual supply voltage should not be 10% less than minimum or 10% greater than rated maximum supply voltages listed in table. If actual supply voltage is outside this range, output may not be available.

	60 Hz 3-Phase			
	All Models		500 Models	600 Models
Rated Supply Voltage (V)	208	230	460	460
Rated Maximum Supply Current I_{1max} (A)	94.2	84.9	43.9	48.7
Rated Effective Supply Current I_{1eff} (A)	65.4	59.6	31.1	40.9
Maximum Recommended Standard Fuse Rating In Amperes ¹				
Time Delay Fuses ²	110	100	50	50
Normal Operating Fuses ³	125	125	60	60
Maximum Recommended Supply Conductor Length In Feet (Meters) ⁴	122 (37)	97 (30)	247 (75)	247 (75)
Raceway Installation				
Minimum Supply Conductor Size In AWG (mm ²) ⁵	4 (25)	6 (16)	8 (10)	8 (10)
Minimum Grounding Conductor Size In AWG (mm ²) ⁵	6 (16)	6 (16)	10 (6.0)	10 (6.0)
Flexible Cord Installation				
Minimum Supply Conductor Size In AWG (mm ²) ⁶	2 (35)	4 (25)	8 (10)	8 (10)
Minimum Outside Diameter Of Cord In Inches (mm)	-	0.865 (22)	0.787 (20)	0.787 (20)
Maximum Outside Diameter Of Cord In Inches (mm)	-	1.260 (32)	1.020 (26)	1.020 (26)
Recommended Strain Relief ⁷	Customer Supplied	See Parts List	See Parts List	See Parts List

Reference: 2026 National Electrical Code (NEC) (including article 630)

1 If a circuit breaker is used in place of a fuse, choose a circuit breaker with time-current curves comparable to the recommended fuse.

2 "Time-Delay" fuses are UL class "RK5". See UL 248.

3 "Normal Operating" (general purpose - no intentional delay) fuses are UL class "K5" (up to and including 60 amps), and UL class "H" (65 amps and above). See UL 248.


4 Maximum total length of copper supply conductors in entire installation (raceway and/or flexible cord).

5 Raceway conductor size is determined per NEC Table 310.16 for insulated copper conductors having a temperature rating of 75°C (167°F) with not more than three single current-carrying conductors in the raceway, corrected for an ambient temperature of 40°C per Table 310.15(B)(1) (1).



6 Flexible cord conductor size is determined per NEC Table 400.5(A)(1) for SOOW cable, corrected for an ambient temperature of 40°C per Table 310.15(B)(1)(1). Flexible cord used for connection to the power supply system shall comply with the requirements of UL 62.

7 If necessary, have a qualified person enlarge access hole in machine panel to accommodate strain relief.

4-8. Connecting Input Power




NOTICE - Do not connect input conductors to contactors W1 or W2.




 Turn Off welding power source.	Welding Power Source Input Power Connections	Disconnect Device Input Power Connections
 Installation must meet all National and Local Codes—have only qualified persons make this installation.	2 Strain Relief Kit (Supplied With Machine)	10 Disconnect Device (switch shown in the OFF position)
 Disconnect and lockout/tagout input power before connecting input conductors from unit. Follow established procedures regarding the installation and removal of lockout/tagout devices.	Install strain relief as explained in instructions supplied with kit.	11 Disconnect Device Grounding Terminal
 Make input power connections to the welding power source first.	3 Input Power Connection Block TE1	12 Disconnect Device Line Terminals
 Always connect green or green/yellow conductor to supply grounding terminal first, and never to a line terminal.	4 Contactor W1	Connect green or green/yellow grounding conductor to disconnect device grounding terminal first.
See rating label on unit and check input voltage available at site.	5 Contactor W2	Connect input conductors L1, L2, and L3 to disconnect device line terminals.
1 Input Power Conductors (Customer Supplied Cord)	6 Welding Power Source Grounding Terminal	13 Over-Current Protection
Select size and length of conductors using Electrical Service Guide. Conductors must comply with national, state, and local electrical codes. If applicable, use lugs of proper amperage capacity and correct hole size.	7 Green Or Green/Yellow Grounding Conductor Connect green or green/yellow grounding conductor to machine grounding terminal first.	Select type and size of over-current protection using Electrical Service Guide (fused disconnect switch shown).
	8 Welding Power Source Line Terminals	Close and secure door on disconnect device. Remove lockout/tagout device, and place switch in the On position.
	9 Input Conductors (L1, L2, And L3) Connect input conductors L1, L2, and L3 to welding power source line terminals.	
	Reinstall side panel on welding power source.	

SECTION 5 – RECOMMENDED SET-UP PROCEDURES

5-1. Typical Connection For GMAW/GMAW-P/FCAW Process



5-2. Welding Circuit



Minimizing the welding circuit loop can prevent extreme voltage drops that produce poor welding characteristics.

- 1 Welding Power Source
- 2 Electrode Cable
- 3 ArcConnect Cable
- 4 Work Cable
- 5 Wire Feeder
- 6 Robot
- 7 Voltage Sensing Lead
- 8 Work Piece

In pulse welding applications using inverter power sources, cable resistance can result in less than satisfactory performance. In most cases, a welding circuit length of 50 ft (15 m) or less will provide satisfactory performance with a standard welding circuit connection.

The length of a welding circuit is determined as follows:

Welding Circuit = Electrode Cable Length (ECL) + Work Cable Length (WCL) + Workpiece Length (WL)

See **Selecting Cable Sizes** for weld cable size.


Variations in welding processes and welding circuit resistance can affect apparent voltage at the welding arc. Voltage sensing can improve welding performance by providing accurate feedback to the welding power source.

It is important to connect the voltage sensing lead as near to the weld as possible but not in the return current path.

5-3. Arranging Welding Cables To Reduce Welding Circuit Inductance



Bad



- 1 Welding Power Source
- 2 Electrode Cable
- 3 ArcConnect Cable
- 4 Work Cable
- 5 Wire Feeder
- 6 Robot
- 7 Voltage Sensing Lead
- 8 Work Piece

The arrangement of the cables has an effect that is significant to the welding properties. As an example, Accupulse welding process can produce high welding circuit inductance depending on cable length and arrangement. This can result in limited current rise during droplet transfer into the welding puddle.


Do not coil excess cables. Use cables that are the appropriate length for the application. Whenever using long weld cables [longer than 50 ft (15 m)] try to arrange positive and negative weld cables together to reduce the magnetic field surrounding the cables. Avoid coupling the feeder and volt sense leads with the weld cables.

A volt sense lead can be used to compensate for work cable drop when connected to the welding power source.


Keep Work and Electrode leads as close together as possible to minimize welding circuit inductance. Route volt sense lead and control cables at least 1 foot away from electrode and work leads.

It is important to connect the voltage sensing lead as near to the weld as possible, but not in the return current path.


Better



Best



5-4. Using Multiple Welding Power Sources



Turn off power before making connections.

- 1 Welding Power Source
- 2 Electrode Cable
- 3 Feeder Cable
- 4 Work Cable
- 5 Wire Feeder
- 6 Robot
- 7 Voltage Sensing Lead
- 8 Work Piece

Each welding power source should have a separate work cable connection to the workpiece. Do not stack or join work cables together at the workpiece. This is very important for pulse welding applications.

It is important to connect the voltage sensing lead as near to the weld as possible, but not in the return current path.

Connect voltage sensing lead at the end of the weld joint.

The direction of the welding path should be away from the work cable connections.

Connect work clamp at the beginning of the weld joint.


Each welding gun should have its own source of shielding gas. Use a separate shielding gas regulator and shielding gas connection for each welding gun.

Arc blow is the deflection of a welding arc from its normal path due to magnetic forces. It will adversely affect the appearance of a

weld, cause excessive spatter, and impair the quality of a weld.

Arc blow occurs primarily during the welding of steel or ferromagnetic metals. Weld current will take the path of least resistance, but not always the most direct path through the workpiece to the work lead connection. The most intense magnet force will be around the arc due to a difference in resistance for the magnetic path in the base metal. The work clamp connection is important and should be placed at the starting point of a weld. It is recommended to have as short of an arc as possible so that there is less of an arc for the magnetic forces to control. Conditions affecting the magnetic force acting on the arc vary so widely that the reference here is only about cabling connections and arc preferences.

5-5. Voltage Sensing Lead And Work Cable Connections For Multiple Welding Arcs





- 1 Welding Power Source
- 2 Electrode Cable
- 3 Feeder Cable
- 4 Work Cable
- 5 Wire Feeder
- 6 Robot

- 7 Voltage Sensing Lead
- 8 Work Piece

This arrangement is a bad setup due to sensing leads being directly in the current flow path of the welding arc. Interaction between welding circuits will affect voltage

drop in the workpiece. The voltage drop across the workpiece will not be measured correctly for the voltage feedback signal. Voltage feedback to the welding power sources will not be correct at either sense lead and result in poor arc starts and arc quality.

5-6. Voltage Sensing Lead And Work Cable Connections For Multiple Welding Arcs (continued)



- 1 Welding Power Source
- 2 Electrode Cable
- 3 Feeder Cable
- 4 Work Cable
- 5 Wire Feeder
- 6 Robot
- 7 Voltage Sensing Lead

- 8 Work Piece


The top arrangement is a better setup for supporting separate voltage feedback to the welding power sources. The most accurate voltage sensing may not be achieved due to voltage drops in the workpiece. This may

require compensation in the welding parameters.

The bottom arrangement is the best setup for proper voltage sensing at the work piece. Voltage feedback to the welding power sources will be more accurate and result in reliable arc starts and better arc quality.

5-7. Earth Grounding

A. Earth Ground Connections to Stationary Robot System Components



⚠ Do not mount anything inside robot control cabinet.

- 1 Line Disconnect Switch Boxes
- 2 Input Power Supply Lines

🔧 Use proper size input and ground conductors for the input power supply line voltage.

🔧 If using conduit, isolate it from robot control cabinet.

- 3 Input Power Supply Ground
- 4 Earth Ground Location

🔧 Make separate equipment earth ground using a minimum of No. 3 gauge copper braided cable that provides a resistance value of less than 100 Ohms between the component connection and the ground wire.

- 5 Welding Power Source
- 6 Work Table Grounding Terminal
- 7 Work Weld Cable
- 8 Work Table Ground Bonding Cable
- 9 Work Table
- 10 Robot
- 11 Insulating Plate (Under Robot Control)
- 12 Robot Control



🔧 Make ground lead 5ft. (1.5 m) to 10 ft (3 m) longer and coil inside robot control.

- 13 Insulating Liner Strips

MAXIMUM MEASUREMENTS

A	5 ft. (1.5 m)
B	10 ft. (3 m)
C	15 ft. (4.5 m)

B. Grounding to Work Table



⚠ Always ground power source frame to work table to prevent electric shock hazards.

1 Equipment Grounding Terminal (On Rear

Panel)

2 Grounding Cable (Not Supplied)

3 Work Table

Connect cable from equipment ground terminal to work table. Use #8 AWG or larger insulated copper wire.

5-8. 30 Points Of Mechanics In MIG Welding

Primary Power

- Check primary power connection at line disconnect switch or receptacle and/or cord plug.
- Check primary power connection at welding power source.

Secondary Power

- Check secondary weld output connections at welding power source.
- Inspect condition and routing of positive weld cable to wire drive motor.
- Check connection of positive weld cable to wire drive motor.
- Inspect condition and routing of negative weld cable to fixture.
- Check connection of negative weld cable to fixture.
- Inspect condition of any rotary grounds, grounding shoes or other auxiliary grounds.
- Check installation, routing and condition of welding gun.

Shielding Gas

- Check gas hose connection to shielding gas supply regulator.
- Check shielding gas flow rate.
- Check gas hose routing.
- Check gas hose connection at wire drive housing.
- Check gun connection at wire drive and be sure O-rings seal at drive housing.
- Check condition of gas diffuser.
- Check condition of nozzle.
- Check O-ring for proper sealing at nozzle.

Welding Wire

- Inspect condition of de-reeler. Check for wear at quick-connect coupling and replace if necessary.

- Check placement of payoff pack or drum for smooth feed path.
- Inspect condition and routing of input conduit.
- Check installation of quick-connect coupling at rear of wire drive so that it does not contact drive rolls. Check for wear and replace if necessary.
- Check drive rolls and replace if worn.
- Check for drive roll tension setting.
- Check intermediate guide for proper size to match wire size and replace if worn.
- Check for proper length of liner at both ends and be sure it is cut without burrs.
- Check liner for proper size to match wire size.
- Check liner for wear and clean out to prevent plugging.
- Check contact tip for proper size to match wire size.
- Check contact tip for wear and change at regular intervals.
- Check contact tip for a tight fit and secure installation at gun.

5-9. Arc Blow

Arc blow is the deflection of the welding arc from its normal path due to magnetic forces. This condition is usually encountered in direct current welding of magnetic materials, such as iron and nickel. Arc blow can happen in alternating current welding under certain conditions, but these cases are rare and the intensity of the arc blow is always less severe. Direct current flowing through the electrode and base metal will set up a magnetic field around the electrode. This magnetic field tends to deflect the arc to the side at times, but usually the arc deflects either forward or backwards along the joint.

Back blow is encountered when welding toward the work cable connection on a workpiece near the end of a joint or into a corner. Forward blow is encountered when welding away from the work cable connection on a workpiece at the start of a joint. In general, arc blow is the result of two basic conditions:

- 1 The change of current flow direction as it enters the work and is conducted toward the work cable.
- 2 The asymmetric arrangement of magnetic material around the arc, a condition that normally exists when welding is performed near the end of ferromagnetic materials.

Although arc blow cannot always be completely eliminated, it can be controlled or reduced to an acceptable level through knowledge of the two conditions listed above.

Except in cases where arc blow is unusually severe, certain steps can be taken to eliminate or reduces its severity. Some or all of the following steps may be necessary:

- Place work cable connection as far as possible from joints to be welded.
- If back blow is the problem, place the work cable connection at the start of the joint to be welded and weld toward a heavy tack weld.
- If forward blow is the problem, place the work cable connection at the end of the joint to be welded.
- Position electrode angle so that arc force counteracts arc blow.
- Use the shortest possible arc that maintains good welding practices (this helps arc force to counteract arc blow).
- Reduce welding current if possible.
- Weld toward a heavy tack weld or runoff tab.
- Use the back step sequence of welding.
- Wrap the work cable around the workpiece in the direction that sets up a magnetic field to counteract the magnetic field causing the arc blow.

5-10. Basic Welding Troubleshooting

Listed below are some problems, causes and remedies related to welding operations; however, this list does not contain every possible condition that could be encountered in welding.


Trouble	Probable Cause	Remedy
No weld output; unit completely inoperative.	Line disconnect switch in Off position.	Place switch in On position.
	Power source switch in Off position.	Place switch in On position.
	Primary power fuse blown or circuit breaker tripped.	Replace fuse or reset circuit breaker and check input voltage.
Weld output is present, but wire stops feeding while welding.	Wire feeder protective fuse blown or circuit breaker tripped.	Replace fuse or reset circuit breaker and find overload condition.
	Wire feeder drive rolls misaligned	Align drive rolls.
	Wrong size drive rolls	Replace with proper size drive rolls.
	Too much or too little drive roll pressure.	Adjust drive roll pressure
	Too much tension set at wire spool.	Reduce wire spool tension.
	Restriction in unspooler or drum adapter.	Replace unspooler or repair restriction.
	Feeder motor burnt out.	Test motor and replace if necessary.
	Gun liner dirty or restricted.	Remove gun liner and clean or replace.
	Wrong type or size of liner.	Install proper size liner.
	Broken or damaged gun or torch.	Replace faulty parts.
	Contact tip opening restricted.	Replace contact tip.
	Wrong size or type of contact tip.	Replace with proper size and type contact tip.

Trouble	Probable Cause	Remedy
	Sharp bends or kinks in gun cable or liner.	Straighten gun cable and/or replace liner.
	Gun overheating.	Use gun with proper amperage rating.
	Wrong size wire.	Match wire size to liner and contact tip.
	Guides rubbing on drive rolls.	Adjust or position guides properly.
	Drive rolls jammed.	Remove foreign object from gears.
	Motor cable disconnected or damaged.	Connect, repair or replace motor cable.
Porosity in Weld	Dirty base metal, heavy oxides, mill scale, oil etc.	Clean base metal by brushing, grinding or use chemical cleansing before welding.
	Regulator/flowmeter faulty.	Adjust or replace regulator/flowmeter.
	Gas cylinder valve closed.	Open gas cylinder valve.
	Gas regulator diaphragm defective.	Replace regulator.
	Flowmeter cracked or broken.	Repair or replace flowmeter.
	Gas hose disconnected or leaking.	Connect or replace gas hose.
	Too much or too little gas flow.	Adjust for proper gas flow.
	Moisture in shielding gas.	Replace gas cylinder or supply.
	Wrong gas for wire type or transfer mode.	Use correct shielding gas.
	Feeder gas solenoid faulty.	Replace solenoid
	Gun or outlet cable leaking.	Repair or replace faulty parts.
	Wire feed speed setting too high.	Reduce wire feed speed.
	Contact tip extends too far out of nozzle.	Adjust or replace parts (max distance should not exceed 1/8 in (3.2 mm)).
	Nozzle to work distance too large.	Reduce nozzle to work distance.
	Incorrect gun or torch angle.	Set proper gun angle (porosity or dirty welds mean gun angle is too large).
	Nozzle Restriction	Clean off spatter or remove restriction.
	Breeze or drafts in weld zone.	Shield weld zone from drafts
	Low shielding gas cylinder pressure.	Replace gas cylinder.
	Gas leak at gun to feeder connection.	Properly install gun or replace O-rings at gun connector.
Excessive Spatter	Voltage set too high.	Reduce voltage setting (reduce trim or arc adjust for pulse welding).
	Incorrect gun or torch angle.	Set proper gun angle.
	Too much or too little gas flow.	Adjust for proper gas flow.
	Wrong gas for wire type or transfer mode.	Use correct shielding gas.
	Wrong electrode wire type or size.	Use proper electrode wire.
	Wrong inductance setting.	Adjust inductance.
	Electrode wire dirty or old.	Replace with new electrode wire.
	Oily or dirty base metal.	Clean base metal by brushing, grinding or use chemical cleansing before welding.
	Distance too great for wire stick-out or nozzle to work.	Adjust wire stick-out or reduce nozzle to work distance.
	Wrong transfer mode.	Set proper transfer mode.
	Travel speed too slow.	Increase travel speed so that arc is on leading edge of weld puddle.
Wandering, hunting or erratic arc.	Restriction in unspooler or drum adapter.	Replace unspooler or repair restriction.
	Dirty or worn gun liner or inlet cable.	Remove gun liner or inlet cable and clean or replace.
	Sharp bends or kinks in gun cable or liner.	Straighten gun cable and/or replace liner.
	Loose or worn contact tip.	Tighten or replace contact tip.
	Wrong size or type of contact tip.	Replace with proper size and type contact tip.
	Gun overheating.	Use gun with proper amperage rating.
	Loose power cables or other electrical connections.	Tighten, repair or replace connections or cables, also check all rotary or brush type connections.
	Incorrect gun or torch angle.	Set proper gun angle.
	Too much or too little gas flow.	Adjust for proper gas flow
	Moisture in shielding gas.	Replace gas cylinder or supply.


Trouble	Probable Cause	Remedy
	Wrong gas for wire type or transfer mode	Use correct shielding gas.
	Wrong program selection for pulse welding.	Make proper program selection.
	Improper or unsteady analog command from robot controller.	Check signal from robot controller (as a troubleshooting aid go to power source control of voltage and wire speed).
	Gun or outlet cable leaking.	Repair or replace faulty parts.
	Incorrect nozzle to work distance.	Set proper distance [3/8 in to 5/8 in (9.5 to 15.9 mm) for short arc, 5/8 in to 1 in (15.9 to 25.4 mm) for pulse welding, and 3/4 in to 1-1/4 in (19.1 to 31.8 mm) for spray welding].
	Voltage sensing leads open or shorted.	Repair or replace voltage sense leads.
	High frequency noise in the area.	Be sure proper grounding methods are followed when TIG or plasma equipment is used in the area.
	Arc blow.	See section 6–4
	Drive motor tachometer or motor cable open or shorted.	Check drive motor tachometer and cables, and repair or replace.
	Wrong size drive rolls.	Replace with proper size drive rolls.
	Too much or too little drive roll pressure	Adjust drive roll pressure.
Welding wire burns back to contact tip at the start of a weld.	Restriction in wire feed system.	Check inlet cable, gun liner and wire guides.
	Worn drive rolls	Replace drive rolls.
	Wrong size drive rolls.	Replace with proper size drive rolls.
	Improper start parameters	Adjust start parameters.
	Worn contact tip.	Replace contact tip.
	Wrong size or type of contact tip	Replace with proper size and type contact tip.
	Not enough cast in welding wire.	Add a wire straightener to put cast in wire.
Welding wire burns back to contact tip during welding.	Restriction in wire feed system.	Check inlet cable, gun liner and wire guides.
	Worn drive rolls	Replace drive rolls.
	Wrong size drive rolls.	Replace with proper size drive rolls.
	Too much or too little drive roll pressure.	Adjust drive roll pressure.
	Worn contact tip.	Replace contact tip.
	Wrong size or type of contact tip	Replace with proper size and type contact tip.
	Not enough cast in welding wire.	Add a wire straightener to put cast in wire.
Welding wire burns back to contact tip at the end of a weld.	Welding power source output not shutting off.	Make sure all switches are in correct position, repair power source if necessary.
	Burnback setting too high or too long.	Adjust burnback setting or turn off completely.
Arc is shorter than expected	Long cable	Reduce cable length or increase arc length or voltage.
	Issue with voltage sense lead feedback circuit (if equipped).	Verify output LED is blinking while welding, indicating voltage sense lead is connected and being used for compensation.
		Check system setup. See Section 5
	Auto compensation parameters have changed (if equipped).	Rerun auto compensation for new setup.

SECTION 6 – GENERAL OPERATION

6-1. Front Panel



6-2. Rear Panel



6-3. Updating Software

- Step 1.** Visit www.millerwelds.com/support/software and select Auto Deltaweld.
- Step 2.** Open Installation Instructions and follow
- Step 3.** The latest software updates can be found in Download Software Updates.
- NOTICE** – A power cycle must be performed after every software update.


6-4. Obtaining Service.TXT file

SERVICE.TXT file is a text file containing all current part numbers of the system and diagnostic information.

Service File Instructions

- Step 1.** With power source OFF, plug in USB flash drive to the USB port of the power source.
- Step 2.** Turn power source ON
- Step 3.** A SERVICE.TXT file is automatically generated on the USB flash drive when the power source is turned ON.
- Step 4.** Wait until the power source is ready to use. This should take approximately two minutes and is indicated by the robot connection status indicating a connection with the robot or the preset wire feed speed and voltage are displayed.
- Step 5.** Remove USB flash drive from the power source.
- Step 6.** System and diagnostic information are now available for viewing when opening SERVICE.TXT file on a computer.

6-5. Duty Cycle And Overheating (500 Models And 600 Models When Connected To 208/230 VAC)



Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.

If unit overheats, output stops, error message is displayed (see Fault Code Diagnostics), and cooling fan runs. Wait for unit to cool and error message to clear. Reduce amperage or duty cycle before welding.


NOTICE – Exceeding duty cycle can damage unit and void warranty.

100% Duty Cycle At 500 Amperes



Continuous Welding

60% Duty Cycle At 575 Amperes



6 Minutes Welding

4 Minutes Resting


25% Duty Cycle At 650 Amperes




2 1/2 Minutes Welding

7 1/2 Minutes Resting

Overheating



6-6. Duty Cycle And Overheating (600 Models When Connected to 460 VAC)



Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.

If unit overheats, output stops, error message is displayed (see Fault Code Diagnostics), and cooling fan runs. Wait for unit to cool and error message to clear. Reduce amperage or duty cycle before welding.

NOTICE – Exceeding duty cycle can damage unit and void warranty.


401451-B

100% Duty Cycle At 600 Amperes



Continuous Welding


60% Duty Cycle At 700 Amperes



6 Minutes Welding

4 Minutes Resting


40% Duty Cycle At 750 Amperes



4 Minutes Welding

6 Minutes Resting

Overheating



SECTION 7 – INTERFACE CONFIGURATION

The Auto Deltaweld is equipped with a web-based configuration tool that is accessible through a web browser on a computer that is connected to the network address of the power source. This network is accessible by a wired connection through the Ethernet receptacle on the front panel of the power source.

The following machine settings are accessed via the web pages:

- Web Interface Configuration
- Robot interface configuration
 - Communication protocol selection
 - Rear panel Ethernet port network settings
- Memory slot configuration
- Sequence Preset Configuration
- Weld Commands and Status
- Error Settings

7-1. Connecting a PC

Connect a CAT5 or CAT Ethernet cable between the Ethernet port on the PC being used for web page access and the front panel Ethernet Receptacle on the Auto Deltaweld. The default IP address of the front panel Ethernet connection is 169.253.1.32. Configuration of the Ethernet port on the PC so that it is on the same subnet as the power source IP address may be required (i.e. 169.253.xxx.xxx.). Example settings for a default IP address to set on your computers network settings would be IP 169.235.1.10 Mask 255.255.255.0.

After an Ethernet connection has been established between the power source and the PC, open a web browser and enter the IP address of the power source (**169.253.1.32**) into the address bar of the web browser. The web pages will open to the login screen.

When the web pages are accessed for the first time, the user is required to set a password before gaining access to the configuration pages. If a password has been set for the system, the user accesses the system by using the previously set password. To reset the password, a password reset file must be loaded through the USB port.




Figure 7-1. Screen Shown on Initial Access




Figure 7-2. Screen Shown on Subsequent Access

7-2. Auto-Deltaweld Configuration Main Page

The Auto Deltaweld Configuration main page allows the user to access the Web Interface Configuration, Robot Interface Configuration, Memory Slot Configuration, Sequence Preset Configuration, Weld Commands and Status, and Error Settings. The software version information of the Auto Deltaweld components is displayed in the header of this page and could be important information to provide to Miller Service personnel. To access the configuration pages, click the **Edit** button below the item to be configured.




Figure 7-3. Configuration Main Page

A. Robot Interface Configuration




Figure 7-4. Robot Interface Configuration Page

The Interface Configuration portion of this page is used to define the communication protocol used for the robot interface. The options are Modbus TCP or Ethernet IP (EIP). Choose the desired settings and click the **Save** button.

The Network Configuration portion of this page is used to configure the network settings for the robot interface connection on the rear panel of the power source. The IP address and subnet mask are configurable, and the default IP address is 192.168.1.51. Enter the desired settings and click the **Save** button. **The IP address used for the front panel and rear panel Ethernet ports cannot be on the same subnet. For example, if the rear panel Ethernet port uses the default IP address of 192.168.1.51, the front panel Ethernet port cannot use an IP address of 192.168.xxx.xxx.**

The power to the Auto Deltaweld must be turned off and back on for network setting changes to take effect. Cycle the machine power by turning the machine off, waiting until the Power On light goes off, and turning power on again.

There are features in this section to select robot models. If the desired robot model is not there, Default is the proper selection.

There are ways to select how Arc length appears on the front panel of the power supply. The two options are -10 to 10 and 0 to 100. Select the best type that suits the automation application.

B. Memory Slot Configuration

The Auto Deltaweld has eight memory slots that are configurable by the user. When shipped from the factory, the memory slots are configured as listed below with memory slot 1 set as the active memory slot.

- 1 0.045" ER70S 75/25 MIG
- 2 0.035" ER70S 75/25 MIG
- 3 0.045" ER70S 90/10 Accu-Pulse
- 4 0.035" ER70S 90/10 Accu-Pulse
- 5 0.045" 3xx stainless 20x Accu-Pulse
- 6 0.045" 4xx stainless 20x Accu-Pulse
- 7 3/64" 4xxx Aluminum Argon Accu-Pulse
- 8 3/64" 5xxx Aluminum Argon Accu-Pulse

The top portion of the Memory Slot Configuration page shows the current settings within the power source. The active memory slot number is identified numerically at the top and is also underlined in the list of memory slots and their contents. In example Figure [Figure 7-5](#), active memory slot 1 is loaded with a program to weld using Versa-Pulse with a ER70S wire size of .052" with 90/10 Argon C02 shielding gas.




Figure 7-5. Memory Slot Configuration

To change the program selected for a particular memory, click the power source control mode button on the top ribbon of the screen and the button will change colors and remove the red text on the screen saying "Enable Powersource control mode to set memory and programs". Then, set the memory slot to be changed as the active memory. Then, choose the weld program to store in the memory slot. The active memory slot is changed by choosing the desired memory slot number in the Memory drop-down and then clicking **Set Memory**.

The weld program loaded in the active memory is changed by selecting the desired weld program in the weld program selection drop-down and then clicking **Set Program**. It is also possible to select the process by typing in the search bar after clicking the drop down portion of the weld program for active memory.

Only the weld programs available in the model of power source being used will be available in the weld program selection drop-down. After changing all the desired memories make sure to turn off power source control mode as weld variables will not be able to be changed by the robot if this remains on.

C. Contactor

The contactor control page enables the user to turn the output contactor on and off. This feature is intended to be used as a troubleshooting tool in the scenario where the robot is commanding the power source to weld and there is no output from the power source. By turning the output contactor on manually, the status of the power source can be understood.

To turn the output contactor on, click the **Contactor On** button.

To turn the output contactor off, click the **Contactor Off** button.

The state of the output contactor is indicated below the buttons.




Figure 7-6. Contactor Toggle

7-3. Machine Configuration Page

The front Ethernet port settings are accessed from this page.

The Network Information portion of this page is used to configure the network settings for the Ethernet port on the front panel of the power source. The IP address and subnet mask are configurable, and the default IP address is 169.253.1.32. Enter the desired settings and click the **Save** button. **The IP address used for the front panel and rear panel Ethernet ports cannot be on the same subnet. For example, if the rear panel Ethernet port uses the default IP address of 192.168.1.51, the front panel Ethernet port cannot use an IP address of 192.168.xxx.xxx.**

The power to the Auto Deltaweld must be turned off and back on for network setting changes to take effect. Cycle the machine power by turning the machine off, waiting until the Power On light goes off, and turning power on again.




Figure 7-7. Ethernet Setup Page

SECTION 8 – MAINTENANCE AND TROUBLESHOOTING

8-1. Routine Maintenance




⚠ Disconnect power before maintaining.

Service equipment more often if used in severe conditions.

Maintenance Schedule		Every 3 Months	Every 6 Months	Reference Section
Cords and Cables	Visually check condition of cords and cables. Replace damaged cords and cables.	•		
Gas Hoses	Visually check condition of gas hoses. Replace damaged hoses.	•		
Torch Body	Visually check condition of torch body. Replace damaged torch.	•		
Labels	Check and replace labels if damaged.	•		
Weld Connections	Clean and tighten weld terminals.	•		
Inside Unit	Blow out inside of unit.		•	Section 8-2

8-2. Blowing Out Inside Of Unit



8-3. Fault Codes

Left Display – Displays *Help* to indicate a fault.

HELP

HELP

TEMP

300

Right Display – Toggles between the identity and a number to specify fault to aid in troubleshooting.

8-4. Fault Code Diagnostics

Blink Code	Unit Display Toggles Message		Description
1	HELP IN	HELP 1 XX	Indicates a malfunction in the primary power circuit. If this display is shown, contact a Factory Authorized Service Agent.
2	HELP TEMP	HELP 2 XX	Indicates a malfunction in the thermal protection circuitry. If this display is shown, contact a Factory Authorized Service Agent.
3	HELP TEMP	HELP 3 XX	Indicates the left side (secondary) of the unit has overheated. The unit has shut down to allow the fan to cool it (see Section 6-5). Operation will continue when the unit has cooled.
4	HELP TEMP	HELP 4 XX	Indicates the auxiliary circuit has overheated. The unit has shut down to allow the fan to cool it. Operation will continue when the unit has cooled.
5	HELP TEMP	HELP 5 XX	Indicates the right side (primary) of the unit has overheated. The unit has shut down to allow the fan to cool it (see Section 6-5). Operation will continue when the unit has cooled.
6	HELP LINE	HELP 6 XX	Indicates machine has sensed a primary power circuit fault. Turn off unit for five minutes and try again (See Section 4-2). If fault remains, contact a Factory Authorized Service Agent.
7	HELP LINE	HELP 7 XX	
8	HELP OUT	HELP 8 XX	Indicates a malfunction in the secondary power circuit of the unit. Verify welding wire or carbon arc electrode is not touching work piece when Gouge mode is enabled. Press the Gouge button twice to clear the fault message. Check external weld circuit configuration of multiple power sources connected to the common work piece. Repair as necessary. If fault remains, contact a Factory Authorized Service Agent.
9	HELP LINK	HELP 9 XX	Indicates relink board PC8 is not configured correctly for the input voltage (See Section 4-2).
11	HELP COMM	HELP 11 XX	Indicates an internal communication loss condition. Cycle power on the welding power source. If fault remains, contact a Factory Authorized Service Agent.
22	HELP PROC	HELP 22 XX	Indicates an malfunction with wirefeed or robot. Verify wire delivery and robot travel path. If fault remains, contact a Factory Authorized Service Agent.
25	HELP DUTY	HELP 25 XX	Indicates machine has reached Duty Cycle limit (See Section 6-5). Unit must be left on to power the fan for cooling. Duty Cycle limit will automatically reset when unit has cooled.
40	HELP ROBO	HELP 40 XX	Indicates that the robot interface is disconnected or that there is an error with the robot. Check the connection of the interface cable between the robot and power source. Check that the interface cable is not broken. If fault remains, contact a Factory Authorized Service Agent.
Other Codes	HELP XXXX	HELP XXXX	Consult wire feeder owner's manual.

The last two digits in the right display (shown with XX in the table) will indicate a specific fault a Factory Authorized Service Agent can use to troubleshoot the machine.

8-5. Troubleshooting

    		
Trouble	Remedy	
No power on indicator; unit completely inoperative.	Place line disconnect switch in On position (see Section 4-8).	
	Check and replace line fuse(s), if necessary, or reset circuit breaker (see Section 4-8).	
	Check for proper input power connections (see Section 4-8).	
No weld output; Power On Indicator on.	Input voltage outside acceptable range of variation (see Section 4-7).	
	Check, repair, or replace remote control device such as wire feeder or hand control.	
Erratic or improper weld output.	Use proper size and type of weld cable (see Section).	
	Clean and tighten all weld connections.	

	Check for correct polarity.
	Poor weld cable layout. See Section 5-3 for recommended cable arrangement.
	If using weld voltage sense lead, verify cable and connections. Repair or replace as needed.
	 Do not leave unused lead connected to the weld voltage sense terminal.
No 115 volts AC output at duplex receptacle.	Reset supplementary protector CB1 (see Section 4-6).
	Auxiliary circuit overheated. Allow unit to cool with fan On (see Section 6-5).
ArcConnect wire feeder not powering on.	Reset supplementary protector CB2 (see Section 4-6).
Over Temperature Indicator on.	Unit overheated. Allow unit to cool with fan On (see Section 6-5).
Fault Indicator flashing.	Unit indicating fault has occurred (see Sections 8-3 , 8-4).

SECTION 9 – ELECTRICAL DIAGRAMS








Figure 9-1. Circuit Diagram For Auto Deltaweld 500 (208-230/460V)





SECTION 10 – DEFINITIONS

10-1. Additional Safety Symbol Definitions

 Some symbols are found only on CE products.

	Warning! Watch Out! There are possible hazards as shown by the symbols.
	Do not discard product (where applicable) with general waste. Reuse or recycle Waste Electrical and Electronic Equipment (WEEE) by disposing at a designated collection facility. Contact your local recycling office or your local distributor for further information.
	Wear dry insulating gloves. Do not touch electrode with bare hand. Do not wear wet or damaged gloves.
	Protect yourself from electric shock by insulating yourself from work and ground.
	Disconnect input plug or power before working on machine.
	Keep your head out of the fumes.
	Use forced ventilation or local exhaust to remove the fumes.
	Use ventilating fan to remove fumes.
	Keep flammables away from welding. Do not weld near flammables.

	Welding sparks can cause fires. Have a fire extinguisher nearby, and have a watchperson ready to use it.
	Do not weld on drums or any closed containers.
	Do not remove or paint over (cover) the label.
	Drive rolls can injure fingers.
	Welding wire and drive parts are at welding voltage during operation - keep hands and metal objects away.
	Pinch points can injure.
	Wear hat and safety glasses. Use ear protection and button shirt collar. Use welding helmet with correct shade of filter. Wear complete body protection made from leather or flame-resistant clothing (FRC). Body protection includes oil-free clothing such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
	Become trained and read the instructions before working on the machine or welding.

10-2. Miscellaneous Symbols And Definitions

A	Amperage
V	Voltage
I	On
O	Off
	Input Voltage
	Output
	Remote
	Gas Metal Arc Welding (GMAW)
	Flux Cored Arc Welding (FCAW)
+	Positive
-	Negative

	Three-Phase Static Frequency Converter-Transformer-Rectifier
U₂	Conventional Load Voltage
I₂	Rated Welding Current
U₁	Primary Voltage
Hz	Hertz
I_{1eff}	Maximum Effective Supply Current
U₀	Rated No Load Voltage (OCV)
X	Duty Cycle
%	Percent
3~	Three Phase
	Direct Current (DC)

	Suitable For Welding In An Environment With Increased Risk Of Electric Shock
I_{1max}	Rated Maximum Supply Current
IP	Ingress Protection
	Line Connection
	Alternating Current (AC)
	Protective Earth (Ground)
	Frame or Chassis
	Circuit Breaker
	Network Activity
	Network Connection to Robot
	Voltage Sense Input

SECTION 11 – REGULATORY AND COMPLIANCE INFORMATION

11-1. Software Licensing Agreement

The End User License Agreement and any third-party notices and terms and conditions pertaining to third-party software can be found at <https://www.millerwelds.com/eula> and are incorporated by reference herein.

11-2. Information About Default Weld Parameters And Settings

NOTICE – Each welding application is unique. Although certain Miller Electric products are designed to determine and default to certain typical welding parameters and settings based upon specific and relatively limited application variables input by the end user, such default settings are for reference purposes only; and final weld results can be affected by other variables and application-specific circumstances. The appropriateness of all parameters and settings should be evaluated and modified by the end user as necessary based upon application-specific requirements. The end user is solely responsible for selection and coordination of appropriate equipment, adoption or adjustment of default weld parameters and settings, and ultimate quality and durability of all resultant welds. Miller Electric expressly disclaims any and all implied warranties including any implied warranty of fitness for a particular purpose.

11-3. Environmental Specifications

A. IP Rating

IP Rating
IP23 This equipment is designed for outdoor use.

B. Temperature Specifications

Operating Temperature Range*	Storage/Transportation Temperature Range
14 to 104°F (-10 to 40°C)	-4 to 131°F (-20 to 55°C)

*Output is derated at temperatures above 104°F (40°C).

Notes

Notes

Notes



Effective January 1, 2026 (Equipment with a serial number preface of NG or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

LIMITED WARRANTY - Subject to the terms and conditions below, Miller Electric Mfg. LLC, Appleton, Wisconsin, warrants to authorized distributors that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. **THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.**

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Notifications submitted as online warranty claims must provide detailed descriptions of the fault and troubleshooting steps taken to diagnose failed parts. Warranty claims that lack the required information as defined in the Miller Service Operation Guide (SOG) may be denied by Miller.

Miller shall honor warranty claims on warranted equipment listed below in the event of a defect within the warranty coverage time periods listed below. Warranty time periods start on the delivery date of the equipment to the end-user purchaser.

1 5 Years Parts — 3 Years Labor

- Original Main Power Rectifiers Only to Include SCRs, Diodes, and Discrete Rectifier Modules in non-inverter products

2 4 Years Parts (No Labor)

- Auto-Darkening ClearLight 2.0 and 4x Helmet Lenses

3 3 Years — Parts and Labor Unless Specified

- Auto-Darkening Helmet Lenses (No Labor)
- Copilot Collaborative Welding Systems
- Engine and Hydraulic Driven Welder/Generators (Including EnPak) (**NOTE: Engines are Warranted Separately by the Engine Manufacturer.**)
- Handheld Laser Power Sources
- Insight Welding Intelligence Products (Except External Sensors)
- Inverter Power Sources
- Plasma Arc Cutting Power Sources
- Process Controllers
- Semi-Automatic and Automatic Wire Feeders
- Transformer/Rectifier Power Sources

4 2 Years — Parts and Labor

- Auto-Darkening Weld Masks (No Labor)
- Fume Extractors - Filtair 215, Capture 5, Purifier, and Industrial Collector Series

5 1 Year — Parts and Labor Unless Specified

- ArcCapture Camera
- ArcReach Heater
- AugmentedArc, LiveArc, and MobileArc Welding Systems
- Automatic Motion Devices
- Bernard BTB Air-Cooled MIG Guns (No Labor)
- CoolBelt, PAPR Blower, and PAPR Face Shield (No Labor)
- Desiccant Air Dryer System

- Field Options (**NOTE: Field options are covered for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.**)

- RFCS Foot Controls (Except RFCS-RJ45)
- Fume Extractors - Filtair 130, MWX and SWX Series, Standard, Telescopic, and ZoneFlow Extraction Arms and Motor Control Box
- Handheld Laser Torches (No Labor)
- Induction Heating Power Sources, Coolers (**NOTE: Digital Recorders are Warranted Separately by the Manufacturer.**)
- Insight Sensors
- Laser Welding Helmets (No Labor)
- Load Banks
- MDX Series MIG Guns (No Labor)
- Motor-Driven Guns
- Positioners and Controllers
- Racks (For Housing Multiple Power Sources)
- Running Gear/Trailers
- Spoolmate Spoolguns (No Labor)
- Subarc Wire Drive Assemblies
- Supplied Air Respirator (SAR) Boxes and Panels
- TIG Torches (No Labor)
- Tregaskiss Guns (No Labor)
- Venture 150 Battery (Warranted for 1 year or 1000 charge cycles, whichever comes first)
- Water Cooling Systems
- Wireless Remote Foot/Hand Controls and Receivers
- Work Stations/Weld Tables/Weld Booths (No Labor)
- XT Plasma Cutting Torches (No Labor)

6 6 Months — Parts

- 12 Volt Automotive-Style Batteries
- PAPR Batteries

7 90 Days — Parts

- Accessories (Kits)
- ArcReach Heater Quick Wrap and Air Cooled Cables
- Canvas Covers
- Induction Heating Coils and Blankets, Cables, Rolling Inductor, and Non-Electronic Controls
- M-Guns
- Subarc (SAW) Torches and External Cladding Heads
- Remote Controls and RFCS-RJ45
- Replacement Parts (No labor)

Miller's True Blue[®] Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, relays, work station table tops and welding curtains, or parts that fail due to normal wear. (Exception: brushes and relays are covered on all engine-driven products.)**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or

misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

4. Defects caused by accident, unauthorized repair, or improper testing.

MILLER PRODUCTS ARE INTENDED FOR COMMERCIAL AND INDUSTRIAL USERS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

The exclusive remedies for warranty claims are, at Miller's option, either: (1) repair; or (2) replacement; or, if approved in writing by Miller, (3) the pre-approved cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon use). Products may not be returned without Miller's written approval. Return shipment shall be at customer's risk and expense.

The above remedies are F.O.B. Appleton, WI, or Miller's authorized service facility. Transportation and freight are the customer's responsibility. TO THE EXTENT PERMITTED BY LAW, THE REMEDIES HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES REGARDLESS OF THE LEGAL THEORY. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT) REGARDLESS OF THE LEGAL THEORY. ANY WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY, OR REPRESENTATION, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, ARE EXCLUDED AND DISCLAIMED BY MILLER.

Some US states do not allow limiting the duration of an implied warranty or the exclusion of certain damages, so the above limitations may not apply to you. This warranty provides specific legal rights, and other rights may be available depending on your state. In Canada, some provinces provide additional warranties or remedies, and to the extent the law prohibits their waiver, the limitations set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary by province.

Warranty Questions?

Call 1-800-4-A-MILLER for your local Miller distributor.

Your distributor also gives you...

Service

You always get the fast, reliable response you need. Most replacement parts can be in your hands in 24 hours.

Support

Need fast answers to the tough welding questions? The expertise of the distributor and Miller is there to help you, every step of the way.

Owner's Record

Please complete and retain with your personal records.

Model Name	Serial/Style Number
Purchase Date	(Date which equipment was delivered to original customer.)
Distributor	
Address	
City	
State	Zip

For Service

Contact a *DISTRIBUTOR* or *SERVICE AGENCY* near you.

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:	Welding Supplies and Consumables Options and Accessories Personal Protective Equipment (PPE) Service and Repair Replacement Parts Training (Schools, Videos, Books) Welding Process Handbooks To locate a Distributor or Service Agency visit www.millerwelds.com or call 1-800-4-A-Miller
-------------------------------	--

Contact the Delivering Carrier to:	File a claim for loss or damage during shipment. For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.
------------------------------------	--

Miller Electric Mfg. LLC

An Illinois Tool Works Company
1635 West Spencer Street
Appleton, WI 54914 USA

International Headquarters—USA

USA Phone: 920-735-4505
USA & Canada FAX: 920-735-4134
International FAX: 920-735-4125

For International Locations Visit
www.MillerWelds.com

